

TV Sony - Getting started



Select channel:

- (1) Switch on (green key top left)
- (2) Press HOME
- (3) Use arrow keys to go to "Elenco canali"
- (4) Press OK (center cross)
- (5) Use arrow keys to go to "Servizi gratuiti"
- (6) Press OK (center cross)
- (7) Select desired channel
- (8) Press OK (center cross)