



Setting the language:

- (1) Switch on (red key top left)
- (2) Press SETTINGS
- (3) Use arrow keys to go to the "tools" icon
- (4) 2x arrow key to the right
- (5) Select language

Select channel:

- (1) Switch on (red key top left)
- (2) Press LIST
- (3) Press the blue key with four dots on the bottom right
- (4) Select "Fav.-Gr. B"
- (5) Select desired channel from the list on the left
- (6) If the desired channel is not included:
At (4): select DTV